

Safari Bar install

Tools needed:

10mm socket - front fascia bolts

3/4" or 19mm socket with short extension - frame rail and bar bolts

1. Remove 2 bolts holding front bumper fascia on (makes install much easier)
2. Insert bracket into frame rail and loosely install black bolts with lock washer.



3. Loosely attach bar with silver bolts, again using lock washer
4. Firmly tighten black bolts into frame rail making sure that they both are angled the same - bracket should deform slightly when tightened to lock into place
5. Center bar on brackets and tighten
6. Reinstall fascia bolts
7. Retighten all bolts within a few days.